

DATE: 14 October, 2008

TO: Whom It May Concern

FROM: SunMed – Largo, FL USA

RE: Disinfection & Sterilization Procedures for Universal Racine Connector

~~~~~

Universal Racine Connector – Manufacture Part# 3-3013-03

Steam for 30 minutes at 120°C. Cidex can be used, follow manufacturer guidelines.